

INSTALLATION INSTRUCTIONS

USA

INDIVIDUAL

UNI-PLUG DOWN MRI6

Art. No. 220 xxxbz bronze
220 xxxch chrome
220 xxxmc matte chrome



IMPORTANT SAFETY INSTRUCTIONS



1. Read all instructions!
2. Turn off power prior to any work on the systems.
3. Only a qualified electrician should install this hard wired transformer.
4. For all the wire connections, use UL listed Wire Nuts.
5. Only BRUCK fixtures and components may be used with the system.
6. Only BRUCK fixtures and components may be used with the system.
7. Total wattage of the system must never exceed the wattage supplied by the low voltage transformer.
8. Please check that the total lamp wattage does not exceed 50W per circuit or wattage specified by fixture.
9. Secondary connections must be clean and tight to avoid arcing and overheating!
10. Warranty is void in case of unauthorized modifications and/ or improper use.

READ ALL OF THESE INSTALLATION INSTRUCTIONS BEFORE INSTALLING THE SYSTEM

Contents of Delivery:

I Uni-Plug Down MRI6

- Insert the lamp into the socket as far as it will go. Make sure the pin spacing and wattage are correct for your fixture.

- Mount the fixture to the canopy or adaptor by plugging in the Uni-Plug. The Uni-Plug will 'click' when properly inserted. Turn the retaining collar to complete the installation (see diagram).

