


# PARTS GUIDE

**STOP**

Using the Parts Guide below, check to make sure all parts are included in the box.  
 If parts are missing or damaged call 1-888-830-1326.  
**PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE.**

Before installing your fan, record the following information for your records and warranty assistance.


## Fan Parts (Not Drawn to Scale)




99 Blade




2 Hanger Bracket Assembly




7 Hanger Ball / Downrod Assembly




3 Canopy




145 Globe Fitter



Motor / Housing Assembly



150 Glass Globe / Shade



95 Ceiling Decal



125 Mounting Block




75 Balancing Kit




202 Bulb




70 Wire Nut



64 Screw, Wood




65 Screw, Wood




123 Mounting Screw, #1/4-20x1.06




124 Mounting Screw, #1/4-20x1.62



69 Screw, #6-32



62 Screw, Canopy



68 Flat Washer

Model Name \_\_\_\_\_

Catalog No. \_\_\_\_\_

Serial No. \_\_\_\_\_

Date Purchased \_\_\_\_\_

Where Purchased \_\_\_\_\_

**Missing / Broken Parts:**  
 Call 1-888-830-1326

**Fan does not work:**

1. Reference the Trouble Shooting guide in your Instruction Manual.
2. Call your Local Service Center.
3. Call Technical Support at 901-248-2222.

**For additional information on:**  
 Hunter Products • Trouble Shooting  
 Dealer Location • Service Center Locator  
 Call 1-800-448-6837  
[www.hunterfan.com](http://www.hunterfan.com)

## Hardware (Drawn to Scale)

<b>Parts List</b>		<b>Model #</b>	<b>23252</b>
		<b>Asm. Dwg. #</b>	<b>92595-01</b>
		<b>Finish</b>	<b>Tan</b>
<b>Item #</b>	<b>Item Name</b>	<b>Qty</b>	<b>Part #</b>
1	<b>Canopy Assembly</b>		
2	* Hanger Bracket Assembly	1	83877-01-232
3	* Canopy	1	83878-01-174
7	* Hanger Ball / Downrod Assembly	1	83875-01-174
95	Ceiling Decal	1	84140-00-000
99	Blade	4	84109-01-000
123	Mounting Screw, #1/4-20x1.06	4	63994-01-232
124	Mounting Screw, #1/4-20x1.62	4	63994-02-232
125	Mounting Block	4	73837-01-174
145	Globe Fitter	1	73040-01-176
150	Glass Globe/Shade	1	84110-01-000
60	* Hardware Kit	1	92595-00-850
62	Screw, Canopy	3	74510-04-174
64	Screw, Wood	2	06512-01-232
65	Screw, Wood	2	03144-03-232
68	Washer, Flat	4	06301-01-232
69	Screw, 6-32	3	74506-36-232
70	Wire Nut	4	05172-01-000
75	* Balancing Kit	1	07570-01-000
202	Bulb	1	65634-01-000



Hunter Fan Company  
 2500 Frisco Avenue  
 Memphis, TN 38114  
 www.hunterfan.com

98000-01-290  
 04/02/07

# GUÍA DE PIEZAS

STOP


Use la Guía de Piezas de abajo para verificar que todas las piezas estén incluidas en la caja.

Si alguna pieza falta o está dañada, llame al teléfono 1-888-830-1326.

**POR FAVOR NO DEVUELVA ESTE PRODUCTO A LA TIENDA DONDE LO COMPRÓ.**

Antes de instalar su ventilador, anote la información siguiente para sus archivos y asistencia con la garantía.

## Piezas del ventilador (no dibujadas a escala)



Nombre del modelo \_\_\_\_\_

No. de catálogo \_\_\_\_\_

No. de serie \_\_\_\_\_

Fecha de compra \_\_\_\_\_

Lugar donde se compró \_\_\_\_\_

**Si alguna pieza falta o está rota:**  
Llame al teléfono 1-888-830-1326


**Si el ventilador no funciona:**

1. Consulte la guía de localización de fallas en su manual de instrucciones.
2. Llame a su centro local de servicio.
3. Llame al teléfono 901-248-2222 para obtener asistencia técnica.

**Para informaciones adicionales acerca de:**

Productos Hunter • Localización de fallas  
Localización de distribuidores  
Localización de centros de servicio  
Llame al teléfono 1-800-448-6837  
[www.hunterfan.com](http://www.hunterfan.com)

## Herrajes (dibujados a escala)



<b>Lista de piezas</b>		No. del modelo	23252
		No. del dibujo de ensamblaje	92595-01
		Acabado	Marrón ligero
No. del ítem	Nombre del ítem	Cantidad	No. de la pieza
1	<b>Conjunto de la campana</b>		
2	* Conjunto del brazo de suspensión	1	83877-01-232
3	* Campana	1	83878-01-174
7	* <b>Conjunto del tubo de suspensión</b>	1	<b>83875-01-174</b>
95	<b>Calcomanía para el techo</b>	1	<b>84140-00-000</b>
99	<b>Paleta</b>	4	<b>84109-01-000</b>
123	<b>Tornillo de montaje, #1/4-20x1.06</b>	4	<b>63994-01-232</b>
124	<b>Tornillo de montaje, #1/4-20x1.62</b>	4	<b>63994-02-232</b>
125	<b>Bloque de montaje</b>	4	<b>73837-01-174</b>
145	<b>Adaptador del globo</b>	1	<b>73040-01-176</b>
150	<b>Globo / Pantalla</b>	1	<b>84110-01-000</b>
60	* <b>Juego de herrajes</b>	1	<b>92595-00-850</b>
62	Tornillo de la campana	3	74510-04-174
64	Tornillo para madera	2	06512-01-232
65	Tornillo para madera	2	03144-03-232
68	Arandela plana	4	06301-01-232
69	Tornillo #6-32	3	74506-36-232
70	Tuerca para alambre	4	05172-01-000
75	<b>Juego equilibrador</b>	1	<b>07570-01-000</b>
202	Bombilla	1	65634-01-000



Hunter Fan Company  
 2500 Frisco Avenue  
 Memphis, TN 38114  
 www.hunterfan.com

98000-01-290  
 04/02/07