


PARTS GUIDE



Using the Parts Guide below, check to make sure all parts are included in the box
 If parts are missing or damaged call 1-888-830-1326
PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE.

Before installing your fan, record the following information for you records and warranty assistance.

Fan Parts (Not Drawn to Scale)




Model Name _____
 Catalog No. _____
 Serial No. _____
 Date Purchased _____
 Where Purchased _____

Missing / Broken Parts:
 Call 1-888-830-1326

Fan does not work:
 1. Reference the Trouble Shooting guide in you instruction Manual.
 2. Call you Local Service Center.
 3. Call Technical Support at 901-248-2222.

For additional information on:
 Hunter Products • Trouble Shooting
 Dealer Location • Service Center Locator
 Call 1-800-448-6837
www.hunterfan.com

Hardware (Drawn to Scale)



Parts List		Model #	24852
		Asm. Dwg. #	92472-01
		Finish	Blue
Item #	Item Name	Qty	Part #
213	Ceiling Plate	1	84138-01-000
20	Motor Assembly	1	
42	Blade Ring	1	92474-01-119
46	Blade Set	1	74002-26-000
	Hardware Kit		84244-01-102
71	Mounting Isolator	3	63731-01-000
66	Blade Grommet	3	63923-01-000
64	Wood Screw	2	06512-01-000
65	Wood Screw	2	03144-03-000
68	Flat Washer	4	06301-01-000
70	Wire Nuts	4	05172-01-000
	Hardware Kit		84244-03-160
210	Wrench, Hex Nut	1	64066-01-000
159	Hex Nut	10	64895-01-000
67	Blade Assembly Screw	10	63922-01-0000
47	Screw, Blade Iron Armature	5	63755-05-133
75	Balancing Kit	1	07570-01-0000
95	Ceiling Decal	1	92473-01-0000
97	Screw, Shoulder	3	63685-01-0000
114	Screw, Machine #8-32	4	74508-04-232
207	Nosecone	1	83779-01-0000
208	Pressure Sensitive Round Tape	1	55582-01-000
211	Pressure Sensitive Square Tape	1	55583-01-000
209	Black Decal Tape	2	65731-01-000
212	Metal Disk	8	73957-01-000
9	Motor Housing	1	92470-01-173

98000-01-302
 9/29/06