



euro style

Assembly Instructions Barney Shelves


PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer, or fax Euro Style at 415.455.8033.



1




2



3

4



During assembly, hand tighten screws only. When all screws are in place, then tighten completely.