


eurow style™

PLEASE NOTE: Check that you have received all components and hardware before assembling. If you are missing any parts, contact your retailer, or fax Euro Style at 415-455-8033.

Assembly Instructions

Raymond



A 1PC



B 1PC



C 1PC

During assembly, **hand tighten** screws only. When all screws are in place, then tighten them completely.