

Swag Hook

700FJSWG_

1.4



GENERAL PRODUCT INFORMATION:




This product is suitable for indoor dry locations only.


This product must be used with FreeJck Pendant fixtures only.




Mount the Swag Hook




- 1** Mark a point on the ceiling near the pendant fixture where the swag hook is to be mounted.
- 2** Tap the anchor at the marked point into the ceiling up to the threaded portion with a hammer.




- 3** Screw the anchor in the rest of the way with a Phillips screwdriver.



- 4** Mount the threaded washer to the anchor with the #8 screw.



- 5** Screw the swag hook to the threaded washer.



- 6 Hook the fixture pendant wire into the swag hook and tighten the #6-32 set screw snugly with 1/16 Allen wrench provided.

SAVE THESE INSTRUCTIONS!



TECH LIGHTING®

7400 Linder Ave.
Skokie, IL 60077
847.410.4400

www.techlighting.com