


Lamp Type: Halogen Max Wattage: 40W Max Socket Type: G9 Voltage: 120V		
BLING I DOWN	CHIANTI DOWN	LUCY DOWN
320 168bz/MP	321 820bz/MP	320 126bz/MP
320 168ch/MP	321 820ch/MP	320 126ch/MP
320 168mc/MP	321 820mc/MP	320 126mc/MP
320 173bz/MP	321 821bz/MP	320 127bz/MP
320 173ch/MP	321 821ch/MP	320 127ch/MP
320 173mc/MP	321 821mc/MP	320 127mc/MP
320 178bz/MP	321 822bz/MP	320 128bz/MP
320 178ch/MP	321 822ch/MP	320 128ch/MP
320 178mc/MP	321 822mc/MP	320 128mc/MP
321 840bz/MP	321 823bz/MP	
321 840ch/MP	321 823ch/MP	RAINBOW DOWN II
321 840mc/MP	321 823mc/MP	320 725bz/MP
321 841bz/MP		320 725ch/MP
321 841ch/MP	CIRO DOWN	320 725mc/MP
321 842mc/MP	320 116bz/MP	320 726bz/MP
321 843bz/MP	320 116ch/MP	320 726ch/MP
321 843ch/MP	320 116mc/MP	320 726mc/MP
321 843mc/MP	320 118bz/MP	320 728bz/MP
	320 118ch/MP	320 728ch/MP
	320 118mc/MP	320 728mc/MP
BLING II DOWN	320 119bz/MP	320 729bz/MP
320 169bz/MP	320 119ch/MP	320 729ch/MP
320 169ch/MP	320 119mc/MP	320 729mc/MP
320 169mc/MP	320 121bz/MP	320 816bz/MP
320 174bz/MP	320 121ch/MP	320 816ch/MP
320 174ch/MP	320 121mc/MP	320 816mc/MP
320 174mc/MP	320 122bz/MP	320 817bz/MP
320 179bz/MP	320 122ch/MP	320 817ch/MP
320 179ch/MP	320 122mc/MP	320 817mc/MP
320 179mc/MP	320 123bz/MP	320 916bz/MP
	320 123ch/MP	320 916ch/MP
	320 123mc/MP	320 916mc/MP
BOBO DOWN	320 124bz/MP	320 919bz/MP
320 915bz/MP	320 124ch/MP	320 919ch/MP
320 915ch/MP	320 124mc/MP	320 919mc/MP
320 915mc/MP	320 125bz/MP	
320 917bz/MP	320 125ch/MP	SIERRA DOWN
320 917ch/MP	320 125mc/MP	320 114bz/MP
320 917mc/MP		320 114ch/MP
		320 114mc/MP
BOLERO DOWN	CIRO MINI DOWN	SILVA DOWN
320 336bz/MP	321 820bz/MP	320 711bz/MP
320 336ch/MP	321 820ch/MP	320 711ch/MP
320 336mc/MP	321 820mc/MP	320 711mc/MP
320 337bz/MP	321 821bz/MP	320 712bz/MP
320 337ch/MP	321 821ch/MP	320 712ch/MP
320 337mc/MP	321 821mc/MP	320 712mc/MP
320 338bz/MP	321 822bz/MP	320 713bz/MP
320 338ch/MP	321 822ch/MP	320 713ch/MP
320 338mc/MP	321 822mc/MP	320 713mc/MP
320 339bz/MP	321 823bz/MP	320 714bz/MP
320 339ch/MP	321 823ch/MP	320 714ch/MP
320 339mc/MP	321 823mc/MP	320 714mc/MP
		320 715bz/MP
		320 715ch/MP
		320 715mc/MP
		320 716bz/MP
		320 716ch/MP
		320 716mc/MP

Lamp Type: Halogen Max Wattage: 40W Max Socket Type: G9 Voltage: 120V	
ZARA DOWN	
320 151bz/MP	
320 151ch/MP	
320 151mc/MP	
320 152bz/MP	
320 152ch/MP	
320 152mc/MP	
320 153bz/MP	
320 153ch/MP	
320 153mc/MP	
320 154bz/MP	
320 154ch/MP	
320 154mc/MP	
320 156bz/MP	
320 156ch/MP	
320 156mc/MP	
320 157bz/MP	
320 157ch/MP	
320 157mc/MP	
ZON DOWN	
321 801bz/MP	
321 801ch/MP	
321 801mc/MP	

4" G9 KISS CANOPY PENDANTS



TECHNICAL SPECIFICATIONS

Description: Kiss pendant fixture with canopy
Design: Bruck-Team
Lamp: G9

CONTENTS OF DELIVERY

canopy and fixture complete without lamp




IMPORTANT SAFETY INSTRUCTIONS



- Save these instructions and refer to them when additions to or changes to the fixture are made.
- THIS PRODUCT MUST BE INSTALLED BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED, IN ACCORDANCE WITH THE APPLICABLE NEC CODE.
- SUITABLE FOR DRY LOCATION ONLY.
- CAUTION - Do not install any fixture assembly closer than 6 inches from any curtain, or similar combustible material.
- Turn off power prior to any work on the systems.
- Please check that the total lamp wattage does not exceed wattage specified by fixture.
- Warranty is void in case of unauthorized modifications and/ or improper use.

READ ALL OF THESE INSTRUCTIONS BEFORE INSTALLATION


INSTRUCTIONS



INSTRUCTIONS FOR USE


- Connect the wires (A) to the power cables in the wall. Insert the screw (B) through the mounting plate (C). Securely attach and tighten mounting plate to ceiling.
- Green wire should be grounded in accordance with local electrical codes.
- Adjust the cable length by loosening the center cable lock (d) and coiling excess cable inside the canopy.
- Place the canopy cover (E) over the mounting plate (C) and secure it with the allen screws (F) located on the side of the base.

4" G9 KISS CANOPY PENDANTS




CIRO DOWN

- 320 116(bz,ch,mc)/MP
- 320 118(bz,ch,mc)/MP
- 320 119(bz,ch,mc)/MP
- 320 121(bz,ch,mc)/MP
- 320 122(bz,ch,mc)/MP
- 320 123(bz,ch,mc)/MP
- 320 124(bz,ch,mc)/MP
- 320 125(bz,ch,mc)/MP




CIRO MINI DOWN

- 321 830(bz,ch,mc)/MP
- 321 831(bz,ch,mc)/MP
- 321 832(bz,ch,mc)/MP
- 321 833(bz,ch,mc)/MP



SIERRA DOWN


- 320 114bz/MP
- 320 114ch/MP
- 320 114mc/MP



CHIANTI DOWN


- 321 820(bz,ch,mc)/MP
- 321 821(bz,ch,mc)/MP
- 321 822(bz,ch,mc)/MP
- 321 823(bz,ch,mc)/MP

4" G9 KISS CANOPY PENDANTS




ZON DOWN

- 321 801bz/MP
- 321 801ch/MP
- 321 801mc/MP




LUCY DOWN

- 320 126(bz,ch,mc)/MP
- 320 127(bz,ch,mc)/MP
- 320 128(bz,ch,mc)/MP



ZARA DOWN


- 320 151(bz,ch,mc)/MP
- 320 152(bz,ch,mc)/MP
- 320 153(bz,ch,mc)/MP
- 320 154(bz,ch,mc)/MP
- 320 156(bz,ch,mc)/MP
- 320 157(bz,ch,mc)/MP



BOLERO DOWN


- 320 336(bz,ch,mc)/MP
- 320 337(bz,ch,mc)/MP
- 320 338(bz,ch,mc)/MP
- 320 339(bz,ch,mc)/MP

4" G9 KISS CANOPY PENDANTS




BLING I DOWN

- 320 168(bz,ch,mc)/MP
- 320 173(bz,ch,mc)/MP
- 320 178(bz,ch,mc)/MP
- 321 840(bz,ch,mc)/MP
- 321 841(bz,ch,mc)/MP
- 321 842(bz,ch,mc)/MP




BLING II DOWN

- 320 169(bz,ch,mc)/MP
- 320 174(bz,ch,mc)/MP
- 320 179(bz,ch,mc)/MP



SILVA DOWN


- 320 711(bz,ch,mc)/MP
- 320 712(bz,ch,mc)/MP
- 320 713(bz,ch,mc)/MP
- 320 714(bz,ch,mc)/MP
- 320 715(bz,ch,mc)/MP
- 320 716(bz,ch,mc)/MP



BOBO DOWN

- 320 915(bz,ch,mc)/MP
- 320 917(bz,ch,mc)/MP

4" G9 KISS CANOPY PENDANTS



RAINBOW II DOWN

- 320 725(bz,ch,mc)/MP
- 320 726(bz,ch,mc)/MP
- 320 728(bz,ch,mc)/MP
- 320 729(bz,ch,mc)/MP
- 320 816(bz,ch,mc)/MP
- 320 817(bz,ch,mc)/MP
- 320 916(bz,ch,mc)/MP
- 320 919(bz,ch,mc)/MP