



# INSTALLATION INSTRUCTIONS

## V/A

### V/A CHANDELIER DOWN

ART. NO.	300 222ch/dn	chrome, 22" diameter, 75W max, with 3 fixtures
	300 222mc/dn	matte chrome, 22" diameter, 75W max, with 3 fixtures
	300 230ch/dn	chrome, 30" diameter, 150W max, with 6 fixtures
	300 230mc/dn	matte chrome, 30" diameter, 150W max, with 6 fixtures



## IMPORTANT SAFETY INSTRUCTIONS



1. Read all of these installation Instructions before installing the track system.
2. Save these instructions and refer to them when additions to or changes in the track configuration are made.
3. THIS PRODUCT MUST BE INSTALLED BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED, IN ACCORDANCE WITH LOCAL NEC CODE.
4. FOR USE WITH V/A NETWORK ONLY.
5. Do not install the track or any part which contains exposed wires less than 7 feet from the floor.
6. Do not install this rail in damp or wet locations.
7. Do not install fixture assembly closer than 6 inches from any curtain, or similar combustible material.
8. Disconnect electrical power before adding to or changing the configuration of the track.
9. Do not attempt to energize anything other than lighting rail fixtures on the rail. To reduce the risk of fire and electrical shock, do not attempt to connect power tools, extension cords, appliances, and the like to the rail.
10. Total wattage of the system must not exceed 75 or 150W supplied by the low voltage transformers.
11. Suspension cables are conductive and should not touch other parts of the track or crossed.
12. CAUTION! Lamps and fixtures become hot during operation.
13. This track system MUST BE HARD WIRED. For all the wire connections, use Listed Wire Nuts.
14. Secondary connections must be clean and tight to avoid arcing and overheating!
15. Warranty is void in case of unauthorized modifications and/ or improper use.

## READ ALL OF THESE INSTALLATION INSTRUCTIONS BEFORE INSTALLING THE SYSTEM

- The VIA Chandelier can be mounted directly onto any standard junction box with access to the power cables.

- Begin by connecting the two wires from the transformer (A) to the power cables in the wall then slide the notched plastic washer (B) through the mounting screws (C).

- Insert the screw (C) into the mounting plate (D) and slide the plastic washer (E) onto the end of the screw. Align the screws (C) with the J-box and tighten until firmly connected.

- Place the canopy cover (F) over the mounting plate (D) and secure it with the allen screw (G) located on the side of the base.

- Insert a Bi-Pin lamp (H) into the socket (I) and screw on desired glass.

- The chandelier can be shortened to the desired length by loosening the two allen screws (J) located to the side of the power feed.

- Once the desired length is reached, tighten the allen screws (J) and trim off any excess cables from below.

